



## General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

## To replace the hot and cold valve:

1. Loosen grub screw (D7) on the underside of handle (D8) using a 2.5mm A/F allen key.
2. Pull the handle (D8) horizontally away from the tap.
3. Unscrew the valve cover (D6) by hand.
4. Hold the body of the tap (C5) firmly. Using an adjustable spanner unscrew the valve lock nut (D5).
5. Clean the Inside of chamber (D3) with a soft wet cloth.
6. Reassemble the tap in the reverse order replacing valve (D4).

## To replace the filter valve:

1. Unscrew top body cover (B1) by hand and pull vertically away from tap body along tap spout (A5) along with dust cover (B2).
2. Hold the body of the tap (C5) firmly. Using an adjustable ring spanner unscrew the handle lock nut (B3).
3. Pull black filter handle (B5) and white spacer (B4) vertically away from tap body (C5)
4. Loosen grub screw (A9) on the side of inner body (B8) using a 2.5mm A/F allen key and pull tap spout ( A4) vertically away from tap body.
5. Using a 3.0 mm A/F allen key unscrew peg (C2) and pull away horizontally away from inner body (B8).
6. Using a 4.0mm A/F allen key unscrew 2 x bolts (B6) enabling inner body (B8) to be separated from tap body (C5).
7. Place a 7.0mm A/F allen key through valve adapter (C1) and unscrew to replace the valve (C3).
8. Clean any debris from the chamber in the tap body (C5), when reassembling ensure valve (C3) is in the off position and that peg (C2) engages with the internal slot of handle (B5).
9. Reassemble the tap in the reverse order.

## To replace the spout o-rings:

1. Unscrew top body cover (B1) by hand and pull vertically away from tap body along tap spout (A5) along with dust cover (B2).
2. Hold the body of the tap (C5) firmly. Using an adjustable ring spanner unscrew the handle lock nut (B3).
3. Pull black filter handle (B5) and white spacer (B4) vertically away from tap body (C5).
4. Loosen grub screw (A9) on the side of inner body (B8) using a 2.5mm A/F allen key and pull tap spout ( A5) vertically away from tap body.
5. Remove the old o-rings (A7) using a small screwdriver or similar.
6. If worn, remove the white PTFE spacer (A6 & A8).
7. Ensure the inside of the body (B1) and the spout base is clean of dirt and grit with a soft wet cloth.
8. If required locate the new white PTFE spacer (A6 & A8).
9. Carefully locate the new O-rings (A7) onto the spout base (A5).
10. Grease the O-rings thoroughly with silicone or alternative similar grease.
11. Reassemble the tap in the reverse order.

## To adjust twist resistance on filter handle:

1. Follow steps 1 – 3 on the replacement of the filter valve instruction.
2. Remove rubber rings (B9) to loosen twist motion of black filter handle (B5).
3. Reassemble in the reverse.