
## TAP2104 – Deck mixer tap



## General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

## To replace the hot valve:

- 1. Lever out the dust cap (B1) using a small precision screwdriver or fingernail.
- 2. Unscrew the crosshead screw (B2)
- 3. Pull the handle (B3 & B4) away from the tap body.
- 4. Holding the tap body (D1) unscrew the valve (B5) using a 17mm ring spanner or adjustable wrench.
- 5. Clean any debris from the chamber in the tap body (D1).
- 6. Reassemble the tap in the reverse order.

## To replace the spout o-rings:

- 1. Whilst holding body (D1) unscrew the spout locking collar (A4)
- 2. Pull the spout (A3) vertically away from the body (D1).
- 3. Remove the old o-rings (A7& A8 using a small screwdriver or similar.
- 4. If worn, remove the white PTFE spacer (A6)
- 5. Ensure the inside of the body (D1) and the spout base (A3) is clean of dirt and grit with a soft wet cloth.
- 6. If required locate the new white PTFE spacer (A6).
- 7. Carefully locate the new O-rings (A7 & A8) onto the spout base (A3).
- 8. Grease the O-rings (A7 & A8) thoroughly with silicone or alternative similar grease.
- 9. Reassemble the tap in the reverse order.