

Gosford monobloc



General Advice:

- · These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- · Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the hot valve:

- 1. Using a small flat screwdriver lever dust cap (D5) away from the lever (D3).
- 2. Pull the handle (D3) horizontally away from the tap body (B1).
- 3. Unscrew the decorative valve cover (D2)
- 4. Unscrew the valve (D1) using a 17mm ring spanner or adjustable wrench.
- 5. Clean any debris from the chamber in the tap body (B1).
- 6. Reassemble the tap in the reverse order.

To replace the spout o-rings:

- 1. Loosen grub screw (A9) on the rear of body (B1) using a small flathead screwdriver.
- 2. Pull the spout (A4) vertically away from the body (B1).
- 3. Remove the old o-rings (A6 & A7) using a small screwdriver or similar.
- 4. If worn, remove the white PTFE spacer (A5 & A8).
- 5. Ensure the inside of the body (B1) and the spout base is clean of dirt and grit with a soft wet cloth.
- 6. If required locate the new white PTFE spacer (A5 & A8).
- 7. Carefully locate the new O-rings (A6 & A7) onto the spout base (A4).
- 8. Grease the O-rings thoroughly with silicone or alternative similar grease.
- 9. Reassemble the tap in the reverse order.

To replace the hot indice:

- 1. Unscrew the indice collar (D7).
- 2. Push the indice (D8) out from the indice collar (D7).
- 3. Screw the indice collar (D7) into the handle lever (D6).
- 4. Push the indice (D8) into the indice collar (D7).

Note. For previous versions of the tap use a small flat precision screwdriver to lever out the old indice (D8) from the handle lever (D6) then push in the new indice (D8).