



## General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

## To replace the valve:

1. Using a small flat screwdriver or fingernail lever dust cap (C5) away from the handle (C2)
  2. Unscrew screw (C4) using a crosshead or slotted screwdriver.
  3. Pull the handle (D2) and cap (C3) horizontally away from the tap body (B1).
  4. Whilst holding tap body (B1) unscrew the valve (C1) using a 17mm ring spanner or adjustable wrench.
  5. Clean any debris from the chamber in the tap body (B1).
1. Reassemble the tap in the reverse order

## To replace the spout o-rings:

1. Unscrew the spout lock nut (A4) by hand.
2. Pull the spout (A3) vertically away from the body (B1).
3. Remove the old o-rings (A5 & A6) using a small screwdriver or similar.

Note: O-ring (A5) is located inside spout lock nut (A4).

4. If worn, remove the white PTFE spacer which is located above o-ring (A5) inside locking collar (A4).
5. Ensure the inside of the body (B1) and the spout base (A3) is clean of dirt and grit.
6. If required locate the new white PTFE spacer.
7. Carefully locate the new O-rings (A5 & A6) onto the spout (A2).
8. Grease the O-rings (A5 & A6) thoroughly with silicone or alternative similar grease.
9. Reassemble the tap in the reverse order.