TAP2412 – Bolsena Single Lever (Chrome)

Key:	Description:	APX size (mm):	Base material	Colour:	QTY:
A1	Aerator case	24 x 13	Brass	Chrome	1
A2	Aerator	20 x 14	Plastic	White/Light grey	1
A3	Washer	2.5 x 23	Rubber	Black	1
B1	Handle	102 x 40 x 45	Mazak	Chrome	1
B2	Indices	9 x 7	Plastic	Red/Blue	1
B3	Grub screw	M5 x 8	Steel	Silver	1
B4	Decorative shroud	40 x 13	Plastic	Chrome	1
B5	Cartridge bush	12 x 37	Brass	Brass	1
B6	Cartridge	56 x 35	Plastic	Cream	1
C1	Upper body	67 x 41	Brass	Chrome	1
C2	PTFE spacer	38 x 1.3	PTFE	White	1
C3	O-ring	35 x 3	Rubber	Black	2
C4	Spout section	240 x 41	Brass	Chrome	1
C5	PTFE spacer	38 x 1.3	PTFE	White	1
C6	Base plinth	44.5 x 5.5	Brass	Chrome	1
C7	Upper seal	41 x 3	Rubber	Black	1
D1	Fixing studs	M6 x 70	Steel	Silver	2
D2	Lower seal	40 x 3	Rubber	Black	1
D3	Metal horseshoe	48.5 x 2.5	Steel	Silver	1
D4	Fixing nuts	13 x 10 AF	Brass	Brass	2
E1	Hot flexi tail	1⁄2" BSP Male x M10 x 300	Stainless braided hose	Silver	1
E2	Cold flexi tail	1⁄2" BSP Male x M10 x 300	Stainless braided hose	Silver	1
E3	Olive	17 x 6	Brass	Brass	2
E4	Nut	11 x 24 AF	Steel	Silver	2

TAP2412 – Bolsena Single Lever (Chrome)



© Abode Home Products Limited

TAP2412 – Bolsena Single Lever (Chrome)

General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the valve:

- 1. Tilt the handle (B1) into the on position.
- 2. Remove the dust cap (B2) with a fingernail or small screwdriver.
- 3. Loosen grub screw (B3) using a 2.5mm A/F Allen key.
- 4. Pull the handle (B1) horizontally away from the tap.
- 5. Unscrew by hand the decorative cover (B4)
- 6. Hold the body of the tap (C1) firmly. Using an adjustable spanner unscrew the valve lock nut (B5).
- 7. Pull the old valve cartridge (B6) away from the tap.
- 8. Ensure that the valve chamber (C1) is clean of dirt and grit.
- Place the new valve (B6) in the chamber (C1), ensuring the locators on the base of valve (B6) align with the recesses in the chamber of the tap (C1).
- 10. Reassemble the tap in the reverse order.
- 11. If replacing the valve it would be prudent to clean the aerator also.

To replace the spout O-rings:

- 1. Disconnect tap entirely from all fittings listed above.
- 2. Unscrew base plinth (C6) and pull vertically away from spout body (C4).
- 3. Pull spout body (C4) vertically away from tap body (C1).
- 4. Remove the old O-rings (C3) using a small screwdriver or similar. Note the orientation of the O-rings for reassembly.
- 5. If worn, remove the white PTFE spacers (C2 & C5).
- 6. Ensure the inside of the spout (A4) and the body (C6) is clean of dirt and grit.
- 7. If required locate the new white PTFE spacers (C2 & C5).
- 8. Carefully locate the new O-rings (C3) onto the body (C1).
- 9. Grease the O-rings thoroughly with silicone or alternative similar grease.
- 10. Reassemble the tap in the reverse order.

To clean the aerator:

- 1. Holding the spout (C4) using an adjustable or 22mm spanner unscrew the aerator case (A1)
- 2. Push the aerator (A2) out from the centre of the aerator case (A1)
- 3. Using a cloth wipe away any debris from the meshed screens of the aerator (A2)
- 4. Run warm water through the aerator (A2) held in the backwards direction (inwards from dark grey side)
- 5. If the aerator (A2) is blocked due to Limescale deposits, we recommend soaking the aerator in vinegar to loosen the scale, then repeat steps 3 and 4.
- 6. Reassemble the tap in the reverse order.