
## TQSL1 – Quadrant Single Lever



## **General Advice:**

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

## To replace the valve:

- 1. Loosen grub screw (C6) using a 2mm A/F Allen key.
- 2. Pull the handle (C5) horizontally away from the tap body (B1).
- 3. Using a precision screwdriver or similar carefully lever the decorative cap (C4) away from the lock nut (C3).
- 4. Hold the body of the tap (B1) firmly. Using a suitable tool unscrew the valve lock nut (C3.
- 5. Pull the old valve cartridge (C1) away from the tap.
- 6. Unscrew the valve extension (C2) from valve (C1), screw the extension into the new replacement valve (C1). Please note extension (C2) was not present on early versions of this model.
- 7. Ensure that the valve chamber (B1) is clean of dirt and grit.
- 8. Place the new valve (C1) in the chamber (B1), ensuring the locators on the base of valve (C1) align with the recesses in the chamber of the tap (B1).
- 9. Reassemble the tap in the reverse order.

## To replace the spout o-rings:

- 1. Loosen grub screw (A8) on the rear of body (B1) using a 2.5mm A/F allen key.
- 2. Pull the spout (X1) vertically away from the body (B1).
- 3. Remove the old o-rings (A6 & A7) using a small screwdriver or similar.
- 4. If worn, remove the white PTFE spacer (A5).
- 5. Ensure the inside of the body (B1) and the spout base is clean of dirt and grit with a soft wet cloth.
- 6. If required locate the new white PTFE spacer (A5).
- 7. Carefully locate the new O-rings (A6 & A7) onto the spout base (X1).
- 8. Grease the O-rings thoroughly with silicone or alternative similar grease.
- 9. Reassemble the tap in the reverse order.