


# TAP1130 – Garda Filter Tap

Key:	Description:	APX size (mm):	Base material:	Colour:	QTY:
A1	Aerator housing	M22 F	Brass	Chrome	1
A2	Aerator	M22	Plastic	Blue/Grey	1
A3	Rubber gasket	21 OD	Rubber	Black	1
A4	Spout	324 x 235	Brass	Chrome	1
A5	Anti friction split ring	24 OD	Plastic	White	1
A6	o-ring	23 OD	Rubber	Black	1
A7	o-ring	19 OD	Rubber	Black	1
A8	Spout grub screw	M5	Brass	Brass	1
B1	Body	52 DIA x 83	Brass	Chrome	1
B2	Upper seal	47 OD	Rubber	Black	1
B3	Stabilising bracket	88 x 58	Plastic	White	1
B4	Rubber horseshoe	51 X 2	Rubber	Black	1
B5	Metal horseshoe	51 x 5	Metal	Silver	1
B6	Hollow fixing stud	M12 X 110	Brass	Brass	1
B7	Fixing nut	65 x 11 AF	Brass	Brass	1
B8	Fibre seal	10 X 1	Fibre	Red	1
B9	Adaptor nut	25 x 14 AF	Brass	Brass	1
C1	Cold/filter valve	53 x 29	Brass	Brass	1
C2	Valve cover	30 DIA x 37	Brass	Chrome	1
C3	Grub screw	M3 x 5	Steel	Silver	1
C4	Handle	91 x 21	Mazak	Chrome	1
D1	Hot valve	½" CD, length 53mm	Brass	Brass	1
D2	Valve cover	30 DIA x 37	Brass	Chrome	1
D3	Grub screw	M3 x 5	Steel	Silver	1
D4	Handle	91 x 21	Mazak	Chrome	1
D6	Body insert	36 x 8	Brass	Brass	1
E1	Hot tail pipe	245 x 15 x M12	Copper	Copper	1
E2	Cold tail pipe	245 x 15 x M12	Copper	Copper	1
F1	Compression nut	11 x 23 AF	Brass	Silver	1
F2	Compression olive	17 x 6	Copper	Copper	1
F3	3-way valve	42 x 46	Brass	Silver	1
F4	3-way push fit adaptor	33 X 33 AF	Plastic	Grey	1
G1	Filter bracket screws	4 x 28	Steel	Silver	1
G2	Filter bracket	45 x 19	Plastic	White	1
G3	Blue flexible pipe	1000 x 6	Plastic	Blue	1
G4	Filter cartridge	50 x 270	Plastic	White	1
G5	Blue flexible pipe	Off-cut from (G3)	N/A	N/A	1
G6	Pushfit connector	28 x 17 AF	Plastic	Grey	1
X1	Spout o-ring set	N/A	N/A	N/A	1



**LAMONA**  
Exclusive to Howdens Joinery Co.

TAP 1130 - Garda Filter Tap  
service drawing v2

© Abode Home Products Limited  
All rights reserved  
No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Abode Home Products Limited.

#### General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

#### To replace the hot valve:

1. Loosen grub screw (D3) on the underside of handle (D4) using a 2mm A/F allen key.
2. Pull the handle (D4) horizontally away from the tap.
3. Unscrew the valve cover (D2) by hand.
4. Hold the body of the tap (B1) firmly. Using an adjustable or 17mm ring spanner unscrew the valve (D1).
5. Clean the Inside of chamber of (D6) with a soft wet cloth.
6. Reassemble the tap in the reverse order.

#### To replace the cold/filter valve:

1. Loosen grub screw (C3) on the underside of handle (C4) using a 2mm A/F allen key.
2. Pull the handle (C4) horizontally away from the body (B1).
3. Unscrew the valve housing (C2) anticlockwise using the provided tool and pull it away from the body (B1).
4. Pull the old cold/filter valve cartridge (C1) away from the tap body (B1)
5. Clean any debris from the chamber in the tap body (B1).
6. Place the new cold/filter valve (C1) into the valve cover (C2) and push this assembly (C1+C2) into the chamber of (B1) **ensuring that the locating peg on the base of the valve (C1) matches up with the one in the tap chamber (B1).**
7. Push the valve cover (C2) into the body of the tap (B1) and tighten up using the provided tool.
8. Reassemble the handle (C4) onto the splined section of the valve (C1)

#### To replace the spout o-rings:

1. Loosen grub screw (A9) on the rear of body (B1) using a 2.5mm A/F allen key.
2. Pull the spout (A4) vertically away from the body (B1).
3. Remove the old o-rings (A6 & A7) using a small screwdriver or similar.
4. If worn, remove the white PTFE spacer (A5 & A8).
5. Ensure the inside of the body (B1) and the spout base is clean of dirt and grit with a soft wet cloth.
6. If required locate the new white PTFE spacer (A5 & A8).
7. Carefully locate the new O-rings (A6 & A7) onto the spout base (A4).
8. Grease the O-rings thoroughly with silicone or alternative similar grease.
9. Reassemble the tap in the reverse order.